














Important!
Thank you for your purchase. Please open it carefully.
If you encounter any problems during assembly and use,
please contact us through the Amazon email platform.
We have the ability to solve all your problems.
Service tenet - to enable customers to enjoy high-quality service.



H
M
A
B
C
I
K
J
I
D
P
C1
A1
B1
I
K
J
I
D1
F
E
G
T
G1

PARTS LIST LISTEDESPIECES LISTEDEPIEZAS

Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante	Name Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante
A	Upper left back panel		1		H	Top Panel		1	
B	Upper right back panel		1		I	Shelves		4	
A1	Lower left back panel		1		J	The right outer door panel		2	
B1	Lower right back panel		1		K	Left front door panel		2	
C	Upper left side panel		1		L	13/32 "Scre w		6	
D	Upper right side panel		1		M	Top support bar		1	
C1	Lower left side panel		1		N	13/32 "Scre w		68	
D1	Lower right side panel		1		O	Shelf Support		16	
E	Kick Plate		1		P	Middle top panel		1	
F	Bottom Panel		1		Q	magnet		8	
G	Wheel mounting plate		4		R	Fixed caster screws		16	
G1	Wheel		4		S	Door Pivot pin I Shim		4	


PARTS LIST		LISTEDESPIECES					LISTEDEPIEZAS		
Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante	Name Nom Nombre		Part Piece Pieza	Qty Qte	Spare Epargner Sobrante
T	Door stopper		1						
V	Laminate fastening buckle		16						
Y	Anti-tilt rope		1						

1




L×6

2




N×12

3


C1
A1
B1
D1
E
Snap the three buckles on either side of Part E into the three holes in both side panels and then push it down so that it snaps into the bottom of the cabinet.
2
1


N×4

4


P
C1
A1
B1
D1
E


N×10

5




N×4

6




N×14

7




R×16

8



N×4


9



N×7


10


Note: Lock the wheels first, then place the shelf.



N×10


11







O×16

12









V×16

13




N×2

14




S×2

15



Q×4

16




N×1

Y×1

17

The cabinet can be fixed to the wall as needed.



Y×1

18

Problems and Solutions

When the door is closed, it still protrudes outward.
That's because the door is made of steel plate and has stretchability.
You can adjust it according to the method shown in the picture.



