










Installation & Assembly






<p>Ax1</p> 	<p>Bx2</p> 	<p>Cx2</p> 
<p>Dx12</p>  <p>M6x25mm</p>	<p>Ex1</p> 	<p>Fx4</p> 

SPARE (Ersatzteile)




<p>Dx1</p>  <p>M6x25mm</p>	<p>Fx1</p> 	
---	--	--

STEP 1

B		2
C		2



STEP 2

D		12
E		1
F		4

