



5" CLIP FAN

Model: FC05002

⚠ WARNING

CHOKING HAZARD - SMALL PARTS. This is not a toy. Not for children under 3 years old. Do not use where small children can reach it. Do not operate the fan in the presence of explosive or flammable fumes. There is a risk of explosion or leakage if batteries are incorrectly installed. Do not mix old and new batteries. Do not mix alkaline, carbon-zinc or rechargeable batteries. Do not dispose of batteries in fire because batteries may explode or leak.

INSTRUCTIONS

For best performance use fresh alkaline batteries. To install batteries, slide out battery door, insert batteries following (+/-) marks and replace door. To operate, slide switch located on side of fan. If fan does not operate, verify batteries are installed properly.

CLEANING AND STORAGE

Clean using a soft damp cloth. Do not immerse fan in water or allow water to drip into fan. Remove batteries if fan will be stored for more than two weeks.

TROUBLESHOOTING

If fan does not operate, verify batteries are installed properly and nothing is obstructing the fan blades. If fan does not operate with USB cord, check that fan is turned ON, that plug is fully inserted into the jack and that the wall receptacle* or computer is powered ON.

*The following information applies when unit is supplied with USB power adapter.

O2COOL, LLC

Chicago, IL USA

312.951.6700

www.o2-cool.com



▲ ADVERTENCIA

RIESGO DE ASFIXIA: PIEZAS PEQUEÑAS. Este producto no es un juguete. No es adecuado para niños menores de 3 años. No lo deje al alcance de niños pequeños. No use el ventilador en presencia de gases explosivos o inflamables. Existe riesgo de explosión y de filtración si no se instalan las baterías adecuadamente. No mezcle baterías antiguas con nuevas. No mezcle baterías alcalinas, de carbono-cinc o recargables. No incinere las baterías ya que podrían explotar o filtrarse.

INSTRUCCIONES

Para obtener un mejor rendimiento, utilice baterías alcalinas nuevas. Para instalar las baterías, deslice y retire la puerta de las baterías, coloque baterías respetando las marcas (+/-) y vuelva a colocar la puerta. Para hacer funcionar, deslice el interruptor ubicado en la parte lateral del ventilador. Si el ventilador no funciona, verifique que las baterías estén correctamente instaladas.

LIMPIEZA Y ALMACENAMIENTO

Limpie con un paño suave húmedo. No sumerja el ventilador en agua ni deje que le caiga agua al ventilador. Retire las baterías si va a almacenar el ventilador durante más de dos semanas.

SOLUCIÓN DE PROBLEMAS

Si el ventilador no funciona, verifique que las baterías o el adaptador provisto estén correctamente instalados y que nada obstruya las aspas del ventilador. Si el ventilador no funciona con el cable USB o cuando se combina con el cargador USB, verifique que el ventilador esté encendido, que el enchufe esté bien conectado y que el interruptor de la pared* o la computadora tenga alimentación.

*La información a continuación se aplica cuando la unidad se suministra con un adaptador de alimentación USB.

O2COOL, LLC
Chicago, IL USA

312.951.6700

www.o2-cool.com