



The furniture glides

How can one attach four solid wood legs to this cute little sofa?

Just align the built-in screw rods of the solid wood legs with the pre-drilled screw holes on the bottom of the sofa, and then manually screw them in.

Special Reminder: The furniture glides (or feet) are not toys. Do not disassemble or tamper with them. After installation, regularly inspect the tightness and integrity of the screws. It is recommended to perform a check within 7 days after the initial installation and to examine the condition of the glides each time you clean or move the furniture.

Please note: Since the product is handmade, there may be slight variations in the screw alignment positions. Therefore, the solid wood legs are designed to serve as adjustable feet to ensure balance. If you notice any imbalance after attaching the sofa legs for the first time, please slightly adjust the distance you screw in or out the legs that are causing the discrepancy.

