





PRODUCT GUIDE AND INSTALLATION MANUAL




Parts List:




Parts List:




M-N-O (Lamp string)




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 9




Step 8




Step 10




Step 11




Step 13




Step 12



Step 14





REMOTE CONTROLLER

