


Installation & Assembly



Ax4



Bx4



(c-1) (c-2)
Cx10/Cx12



Dx4




x44

x50

x44

x44



Fx24



Gx16



Hx24




Ix12




Jx12



Kx16



Lx8



mm
inch





x1

① x2



Gx16



Fx24




② x2



Hx24




③ x2




Jx12



Ix12



④ x2



Ex44





⑤ x2


Lx8



Kx16



6



7

