

Assembly Instructions

10'x10' Steel Fan Gazebo



Table of Contents

Table of Contents	2
Safety Information	2
Warranty	2
What is Covered	2
What is Not Covered	2
Warning	2
Pre-installation	3
Planning Installation	3

Tools required	3
Hardware Included	3
Package Contents	4
Operation	6

Safety Information

1. SET UP YOUR GAZEBO PROPERLY

- ☐ Do not assemble this item alone. 3 people are recommended for safe assembly.
- ☐ Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- ☐ Keep all children, pets and other obstructions away from assembly area.
- ☐ If any part is missing or damaged, do not attempt to assemble the product.
- ☐ In order to avoid damage to the gazebo and its components please use appropriate tools.
- ☐ Do not use the structure as support.
- ☐ Check all bolts on a regular basis to maintain the solidity of the structure.
- ☐ Keep instructions for future use.



DANGER: Do not assemble this item alone.



WARNING: Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.



CAUTION: Do not climb on top of the gazebo. Falling off the gazebo can result in serious injury, possibly even death.

2. EXAMINE YOUR GAZEBO

- ☐ Examine occasionally to ensure there are no loose parts. If loose parts are found, they should be retightened immediately.

Warranty

1 YEAR WARRANTY FOR FRAME, 1YEAR WARRANTY FOR FABRIC

WHAT IS COVERED

We provide warranty to the original purchase for 1 year for frame and 1 year for fabric from the date of purchase, and the fabric and frame will be replaced at no charge due to manufacturing defects.

WHAT IS NOT COVERED

We do not reimburse for transportation costs. This warranty does not cover the damage caused by commercial use, acts of nature, fire, freezing, and abusive use. Discoloration or fading of the finish or fabrics as a result of chemicals or spills is not covered.

Warning



WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.





Pre-installation

PLANNING INSTALLATION

To prevent damage, place all parts on a soft surface during assembly.
Tools required for assembly (not included): Allen wrench (included), hammer, screwdriver, stepladder, level and other safety items such as gloves, safety goggles and hardhat.

 **NOTE:** Tools and protective articles below are not provided.



TOOLS REQUIRED



HammerScrewdriverSafety gogglesGlovesHardhatStepladderLevel












HARDWARE INCLUDED

 **NOTE:** Hardware not shown to actual size.


K	Plastic Loop	32	
L	Stake	16	

Pre-installation (continued)

PACKAGE CONTENTS

A	Central Connector	1	
B	Long Top Bar	4	
C	Short Top Bar	4	
D	Lintel	4	
E	Corner Panel	4	
F	Connector	8	
F1	Bolt (M10*15)	8	
G	Shelf	4	
H	Small Canopy	1	
I	Large Canopy	1	
J	Mosquito Netting	4	


1



1. Unfold two Corner panels (E), then insert the ends of a Lintel (D) into the corner panels (E), attach the Lintel (D) to the Corner panel (E) with Connector (F) and Bolt (F1). Repeat the procedure for the remaining corner panels (E) and Lintels (D).


Note: The hole of the crossbeam (D) inside.

2



2. Attach the Central Connector (A) to the Long Top Bar (B) using the Push Button.
3. Insert the Long Top Bar (B) into the corner tube of Corner panels (E).


3



4. Attach the Central Connector (A) to the Short Top Bar (C) using the Push Button.


5. Attach the other end of Short Top Bar (C) to the Lintel (D) using the Push Button.

4




6. Slide the Large Canopy (I) onto the top of the gazebo (do not tighten at this stage); place the small Canopy(H) onto the Small Top Bar, then tighten the Canopy.

5



7. Place Shelves (G) onto Corner panels (E) as desired.

6



8. Hang the Mosquito Netting (J) on the Corner panels (E) with Plastic Loop (K).

9. Adjust the position of the gazebo, and anchor the gazebo to the ground by inserting the Stakes (L) into holes of each Corner panel (E).

Now your gazebo is completely assembled.