




EXPANSION SCREW INSTALLATION METHOD




1

Use a drill to drill into the wall and
Expansion tube size--induced hole



2

Install the expansion screw into the hole, use
Tighten the hex nut with a wrench



3

Expansion tube opens after force
The tail hangs on the wall