ASSEMBLY INSTRUCTION

Ax1



Ex12



Bx1



Fx1

Cx2



Gx4



Dx4