



# Product Instruction

DJ0907-A

DJ0907-B







**A+B+B**





**A+B**

**A**  
(Sofa)




**B**  
(Stool+Median)




# Instruction



## STEP:1






## STEP:2



## STEP:4



## STEP:3



The sofa cushions need 72hours to decompress and fully inflate before using them.

If you find wrinkles in the fabric after 72 hours, you can use a steam ironing treatment. The back cushions are removable and washable, while other non-removable parts can be cleaned with a detergent.