









Door Adjustment



Adjust the screw to make the door lean to forward or back



Adjust the screw to make the door lean to left or right



Adjust the screw to make the door lean to up or down