


# Assembly Instructions





**Caution:** •You must read this before you proceed.

•Sets often ship in multiple boxes and may arrive a day or two apart.










## EXTENTION DINING TABLE



## Parts List





Label	Picture	Description	QTY
A		Table Top	1
B		Pedestal Leg	4
C		Pedestal Column	1
D		Mounting Plate (Unloose from Step 2)	1

# Hardware

Label	Picture	Description	QTY
①		Allen Wrench	1
②		Bolt (M6x50mm)	7
③		Spring Washer Ring (M6x11mm)	7
④		Flat Washer Ring (M6x19mm)	7
⑤		Wrench	1
⑥		Nut (M8)	13
⑦		Spring Washer Ring (M8x13mm)	13
⑧		Flat Washer Ring (M8x22mm)	13
⑨		Adjustable Glider	5

# Assembly Preparation

Before  
Beginnin  
g  
Assembl  
y:



X1



X3



X3



X3



X1



X13



X13



X13



X5



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


## Assembly Steps

### Overview




This Table has multiple parts and may require up to 60 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise yourself with the parts and steps before assembly.

### Step 1




Unpack and place all parts on a clean, non-marring surface.

### Step 2



Please loosen the 4pcs Bolts, Spring Washer Rings and Flat Washer Rings from the Mounting Plate (D) using the Allen Wrench (①). Keep the hardware for Step 6.


### Step 3



Attach the Mounting Plate (D) to the Pedestal Column (C) using Nuts ((6)), Spring Washer Rings ((7)) & Flat Washer Rings ((8)) and the Wrench ((5)).

**PLEASE FULLY TIGHTEN SCREWS.**


### Step 4



Attach the Pedestal Legs (B) to the Pedestal Column (C) using Nuts ((6)), Spring Washer Rings ((7)) & Flat Washer Rings ((8)) with the Wrench ((5)).

**FULLY TIGHTEN ALL THE NUTS.**

## Step 5




Insert the Adjustable Gliders (⑨) into the Pedestal Legs (B) as shown above.

**FULLY TIGHTEN ALL THE GLIDERS.**

## Step 6


Hardware from Step 2. Include Hardware list.



Place the the Table Top (A) on a clean non-marring surface, then place the assembled table parts from Step 5 on top of it. Affix the Table Top (A) to the Mounting Plate (D) with Bolts (②), Spring Washer Rings (③) & Flat Washer Rings (④) using the Allen Wrench (①).


**FULLY TIGHTEN ALL THE BOLTS.**

### Step 7



Stand the Table up with the assistance from your partner. Unlock the latches underneath the Table Top (A). Pull apart the Table Top (A) from both ends.


### Step 8



Take out the leaf. Close the Table Top (A) tightly and lock all latches underneath the Table Top (A).



## Step 9



Place the Table on a LEVEL SURFACE and check that it is balanced. If there is a slight wobble, please adjust the Adjustable Gliders (⑨).

**WARNING: IF TABLE IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.**

Ensure all bolts are fully locked into position.

The Table is ready to be used.

**Caution 1: This Table can only be used on a flat, level surface.**

## Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.