



Installation & Assembly



TV Stand w/ Fireplace


NOTE: This instruction manual contains IMPORTANT safety information. Please read carefully before assembling the product

List of Parts



Hardware

A x 58+2




Ø6 x 34mm

B x 58+2



Ø15 x 10mm

C x 18+1




Ø8*30mm

D x 8+1




Ø3*12mm


E x 4



F x 2



G x 2



Ø4*22mm

H x 4+1



Ø3*16mm

I x 2



J x 28+2



Ø3.5*12mm

K x 12




L x 16+1




Ø3.5*12mm

M x 4




N x 2



STEP 1

A x 4




Ø6 x 34mm

B x 4




Ø15 x 10mm




STEP 2

A x 10



Ø6 x 34mm




STEP 3

B x 6




Ø15 x 10mm



STEP 4

A x 6




Ø6 x 34mm

B x 6




Ø15 x 10mm



STEP 5

A x 2




Ø6 x 34mm

B x 2



Ø15 x 10mm





STEP 6

H x 4




Ø3*16mm

l x 2




STEP 7

A x 4




Ø6 x 34mm




STEP 8

A x 4



Ø6 x 34mm




STEP 9

B x 4




Ø15 x 10mm

C x 4



Ø8*30mm




STEP 10

B x 4




Ø15 x 10mm

C x 2



Ø8*30mm




STEP 11

B x 4




Ø15 x 10mm

C x 2



Ø8*30mm



STEP 12

A x 6





Ø6 x 34mm

L x 8




Ø3.5*12mm

M x 4




STEP 13

A x 8



Ø6 x 34mm




STEP 14

B x 6




Ø15 x 10mm

C x 4



Ø8*30mm




STEP 15

B x 8




Ø15 x 10mm

C x 2



Ø8*30mm




STEP 16

A x 14



Ø6 x 34mm



STEP 17

B x 2





Ø15 x 10mm

D x 8



Ø3*12mm

E x 4




STEP 18

B x 12




Ø15 x 10mm

C x 4



Ø8*30mm




STEP 19

F x 2



G x 2





Ø4*22mm

D x 4



Ø3*12mm

E x 2




STEP 20

L x 8




Ø3.5*12mm



STEP 21

K x 12

TV STAND ASSEMBLY




STEP 22



J x 28






Ø3.5*12mm




STEP 23



Wall



STEP 24




STEP 25

K x 8



FIREPLACE MANTEL ASSEMBLY




STEP 26



J x 16






Ø3.5*12mm




STEP 23




Wall



STEP 24





FIREPLACE INSTALLATION

If you decide to install the fireplace into the mantel, carefully set the unit from the back of the mantel and center it in the opening.

Check the alignment and attach the unit to the mantel by inserting screws through the drilled holes on the trim to the mantel.

NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.