


# ASSEMBLY INSTRUCTIONS




F8346 / F8347 / F8469 / F8470

## 4-PC SECTIONAL SOFA

OPTION #1: CONSOLE ON THE LEFT




OPTION #2: CONSOLE ON THE RIGHT




2 PERSONS RECOMMENDED


BOX-1 F8469-1 / F8470-1 / F8346-1 / F8347-1




x 1 PC




x 1 PC




x 4 PCS



x 4 PCS




x 1 PC




x 16 PCS


BOX-2 F8469-2 / F8470-2 / F8346-2 / F8347-2




x 1 PC




x 2 PCS




x 2 PCS



x 2 PCS




x 1 PC




x 1 PC

BOX-3 F8469-3 / F8470-3 / F8346-3 / F8347-3




x 1 PC


Plug and power cord




STEP-1




STEP-2




STEP-3.1





STEP-3.2 OPTION #1: CONSOLE ON THE LEFT



STEP-3.3 OPTION #2: CONSOLE ON THE RIGHT



STEP-4.1 OPTION #1: CONSOLE ON THE LEFT



STEP-4.2 OPTION #2: CONSOLE ON THE RIGHT

