

# 3 Pieces Wicker Bistro Sofa Set



### **Before You Start**

- Please read all instructions carefully.
- A Retain instructions for future reference.
- ♠ Separate and count all parts and hardware.
- Read through each step carefully and follow the proper order.
- We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- Always place the product on a flat, steady and stable surface.
- Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.



## **Return / Damage Claim Instructions**

#### ♠ DO NOT discard the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

#### ♠ Take a photo of the box markings.


A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.


## /\ Take a photo of the damaged part (if applicable).


A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

#### No Send us an email with the images requested.

Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.











M6x25mm









M6x55mm

(3) x12

Ø6x14x1mm







(5) x12







Allen key / Clé Allen 4x98mm

(7) x2



