


Cabinet

Assembly Instruction – Please keep properly for future reference.

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.



SKU
BG04U6-1C3A0
BG04U6-1C3B0
BG04U6-1C3C0

V1.0

EN

CONTACT US

- **Email: service@grandtunnel.com**
In order to receive assistance more quickly, please provide

THE FOLLOWING INFORMATION:

- Order number
- Purchase platform
- Purchase date
- Detailed description of the issue along with photos (if applicable)

Important – Please read these instructions carefully before starting the installation.

Before Assembly



Thank you for choosing our product!

To ensure a smooth installation process, please read this guide carefully to familiarize yourself with the required tools, materials, and installation steps.

Follow the relevant sections to avoid any damage caused by improper installation, and make sure to review all operation and safety guidelines for correct installation procedures.

Packaging Notice:

If you find any missing boxes, damaged parts, or accessory shortages, please contact the customer service team of your purchasing channel immediately. We will resolve the issue as quickly as possible.

Safety and Care Advice



Important :

Please read these instructions fully before starting assembly.

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.

Warning

In order to help prevent overturning, please follow these instructions.

- Use the anti tip strap or wall fixing method provided (if applicable).
- Do not allow children to climb or hang on the furniture.
- Do not open more than one drawer at a time.
- Do not place heavy items in the top drawers.
- Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.
- Please note that only the anti tip strap is provided. You will need to provide wall plugs and screws applicable for your wall type.

Customer Service Guide



Thank you for choosing our product! We are committed to providing you with excellent service. If you find any missing parts, damaged packaging, or product damage after receiving all packages, please follow the steps below to quickly contact our customer service team. We will do our best to resolve your issue.

1. Missing Parts

Verify Parts:

1. Refer to the “Parts List” in the manual to verify the name, specifications, and quantity of the missing parts.
2. Take a clear photo of the parts list and mark the missing parts with detailed information, e.g., “Missing 5 pieces of M6×30mm screws.”

Contact Us:

By Email:

Send an email to **service@grandtunnel.com**, with the subject line “Missing Parts Issue.” Include the following in the email:

- A description of the missing parts and a photo of the parts list.
- Order details (order number, purchase platform, purchase date).

2. Product or Packaging Damage

If it affects normal use:

Steps:

1. Take clear photos or videos showing the damaged parts and the extent of the damage (multi-angle shots are recommended).
2. Email the photos/videos along with order details to **service@grandtunnel.com**, with the subject line “Product Damage Issue.”

Resolution:

After verification, we will arrange for a replacement part, product exchange, or refund as quickly as possible.

If it does not affect normal use:

Steps:

1. Contact our customer service team (by email: **service@grandtunnel.com**).
2. Provide a description of the damage and include relevant photos or videos.

Resolution:

We will provide repair guidance or an appropriate compensation plan based on the specific situation.

Contact Us:

Customer Service Email: **service@grandtunnel.com**

Helpful Tips

To process your issue efficiently, please prepare the following information:













- Order details (order number, purchase platform, purchase date).
- Clear photos or videos.
- We are committed to providing quick and professional solutions, no matter the size of the issue, to ensure your satisfaction.






Thank you for your trust and support!
We hope you enjoy using our product!

Parts List - Panels



Please check you have all the panels listed below.

		
1 746x400x15mm x1	2 1175x400x15mm x1	3 1175x400x15mm x1
		
4 400x64x27mm x2	5 804x50x15mm x1	6 804x60x15mm x4
		
7 804x80x15mm x2	8 804x100x15mm x1	9 804x125x15mm x1
		
10 798x212x15mm x1	11 798x182x15mm x4	12 300x130x12mm x5









		
13 300x130x12mm x5	14 755x130x12mm x5	15 287x60x12mm x5
		
16 765x297x3mm x5	17 1074x406x3mm x2	

Parts List - Fittings




Please check you have all the fittings listed below.

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied are required.


 A $\Phi 15 \times 9.5$ x74+3	 B $\Phi 6.5 \times 35$ x74+3	 C $\Phi 8 \times 30$ x12+1
 D $\Phi 3.5 \times 14$ x60+3	 E $\Phi 4 \times 35$ x30+3	 F $\Phi 4 \times 50$ x3+1
 G L=300 x5	 G L=300 x5	 G L=300 x5
 G L=300 x5	 H $\Phi 3 \times 14$ x14+1	 I x1
 J 70*30*5 x1	 K x2 set	

Cam Lock Fastening System





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Assembly Instructions





Step 1




Attach hardware piece G to panels 2 and 3 using screws D, as shown in the diagram.







Step 2




Attach hardware piece B to panels 2 and 3.




Step 3



First, attach hardware piece B to panel 8. Then, align panels 8 and 9 using hardware piece C. Insert hardware piece A into the designated hole in panel 9 and turn clockwise to secure.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


Step 4



Insert panels 5, 6, 7, 8, and 9 into the holes on panel 3, as shown. Secure each with hardware piece A by turning clockwise.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


Step 5



Place panel 2 face down with the groove facing the back. Align its holes with panels 5, 6, 7, 8, and 9, and secure with hardware piece A, turning clockwise.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


Step 6



Use hardware piece I to connect panel 17 together, then slide it into the grooves on panels 2 and 3.




Step 7




Attach hardware piece B to panel 4, then install hardware piece C between panels 4 and 1. Secure with hardware piece A, turning clockwise. Finally, attach hardware piece K to panel 1 in alignment.

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK


Step 8



Position panel 1 with the groove facing the back. Align hardware piece C with the holes on panels 2 and 3, insert, and secure with hardware pieces A and F by turning clockwise.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


Step 9



Join panels 12, 13, 14, and 15 using screws E. Insert panel 16 as shown. Attach hardware piece B to panel 10, then flip and secure to panels 12 and 15 with hardware piece A.





Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK




Step 10



Join panels 12, 13, 14, and 15 using screws E. Insert panel 16 as shown. Attach hardware piece B to panel 11, then flip and secure to panels 12 and 15 with hardware piece A.




X4

Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK





Step 11




Attach hardware piece G to panels 12 and 13 using screws D, as shown.



Step 12




Attach hardware piece G to panels 12 and 13 using screws D, as shown.






X4



Step 13




Insert the plastic clips into the slots on the back panel. Turn the clips over the holes and lock them in place.




Step 14




Install the anti-tip device according to the provided instructions.




1. make mark on the wall.




2. drill two Ø6 holes on the wall.



3. put two anchors in the holes.



4. fix the device on the wall by the long screws.



⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

Step 15



Step 16



The cabinet installation is complete.