




**ASSEMBLY INSTRUCTIONS**  
**POWER RECLINING CHAIR WITH WIRELESS**  
**CHARGER, COOLING CUP-HOLDER, STORAGE ARMS,**  
**SPEAKERS, LED LIGHT AND USB PORT**




Back Rest are stored at the bottom of chair, please take out it for assembly hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


**Component list**

No	Drawing	Qty	Description
<b>A</b>		<b>1</b>	<b>SEAT</b>
<b>B</b>		<b>1</b>	<b>BACK REST</b>
<b>C</b>		<b>1</b>	<b>PLUG WITH WIRE</b>


Step #1



Step #2



## Step #3



## Care Instruction for Leather Furniture:

In order to maintain the original appearance of your Leather Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Leather.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.