




Wicker Chandelier

Instruction Manual

Read Carefully Before Use
Keep for Future Reference

Safety Information

Danger

Read these instructions carefully before installation.


- This light fixture can be used by children aged 8 years and older, persons with reduced physical, sensory, or mental capabilities, or those who lack experience or knowledge, ONLY if they are properly supervised or have been instructed in its safe and understand the risks involved.
- Check for electric, gas, and plumbing lines before drilling, or consult a professional.
- ALWAYS cut ALL relevant power before installing the lighting fixture. DO NOT restore power until installation is FULLY complete.
- ALWAYS wear gloves during installation and avoid collisions to prevent injury. Take care not to scratch the fixture or wiring.
- DO NOT mix up the live (black), neutral (white), and ground (bare copper) wires.
- Seek professional assistance from certified electricians if needed.
- DO NOT install the light fixture on uneven, sloped, damaged, or wooden ceilings.
- DO NOT use bulbs exceeding the recommended wattage.

Warning

- Children MUST NOT play with the light fixture.
- Cleaning and maintenance must not be carried out by children without supervision.
- Keep the light fixture and its cord out of the reach of children under 8 years old.
- NEVER leave the light fixture unattended when it is connected to a power supply.
- If the supply cord is damaged, the light fixture should be scrapped or have the cord replaced by the manufacturer, its service agent, or similarly qualified persons to avoid hazards.
- DO NOT change any bulbs with your bare hands while they are hot.
- NEVER reverse the positive and negative poles of the power supply.

Package List

A × 1




E × 1



F × 3




B × 1



G × 2




C × 1



Preinstalled A 2" Light Tube



D × 5



3 × 11.8" + 1×7.87" + 1×3.94" Light Tubes



Assembly

Before screwing the tubes (D), pass the wires through the tubes and canopy (C).




Note: You can install varying light tubes based on your desired height.

Note: Install the mounting bolts **DIAGONALLY**.



Suitable for sloped ceilings up to 90°.



This fixture supports up to E26 bulbs, each up to 60 watts.

10




11




E26 Bulb
(not included)

12



Fit the diffuser (B) into the shade (A). Insert one side first, then press the other side into place.

Pull down the tab until the diffuser (B) firmly sits on the shade's inner roll rim.



Restore power and enjoy your new light fixture!

Troubleshooting

Q1: The light won't turn on.

A:

- Ensure the power is on.
- Check all wiring connections.

Q2: The light flickers or dims intermittently.

A:

- Ensure the fixture is securely connected to the power source.
- Check if the power supply voltage is stable.
- Turn off the power and inspect for loose wiring. Tighten the connections if needed.

Q3: The light is too dim.

A:

- Ensure the power supply voltage meets the fixture's required specifications.
- Ensure the bulbs and the diffuser are all clean and free of dust or debris. Gently wipe with a dry cloth if necessary.

Q4: The light turns off unexpectedly.

A:

- Check if the light is overheating and ensure proper ventilation.
- Verify the circuit breaker isn't tripping due to overload.

Disclaimer

Read this disclaimer completely and carefully before proceeding with the rest of the manual content.

1. Product Modifications

Any modifications or alterations to this product void any warranties and may result in damage or injury. We shall not be liable for any damages resulting from such modifications or alterations.

2. Compliance with Laws

Customers shall be liable for ensuring that the use of this product complies with all applicable laws and regulations in their respective jurisdictions. We shall not be responsible for any violations of laws or regulations resulting from the use of this product.

3. Correct Use

Always use this product only as directed in the accompanying manuals. Failure to follow instructions may result in injury or damage.

Always ensure the assembly, installation, operation, maintenance, or repair of this product is carried out by a competent person.

Regular maintenance should be performed throughout the lifecycle of this product. You are responsible for ensuring this product operate as intended.

Always wear appropriate protective gear.

4. Third-Party Products

We shall not be liable for any damages or losses resulting from the use of third-party products in conjunction with our products. Customers shall refer to the third-party's guidelines or/and warranties (if any) for any third-party products used.

5. Limitation of Liability

We shall not be liable for any direct, indirect, punitive, incidental, special, or consequential damages to property or life, whatsoever arising out of or connected with the use or misuse of our products. In no event shall our liability exceed the value of the products sold.

6. Warranty

Refer to the sales page for warranty information.

This disclaimer states the entire obligation of us with respect to this product. If any part of this disclaimer is determined to be void, invalid, unenforceable, or illegal, including but not limited to the warranty disclaimers, liability disclaimers, and liability limitations set forth above, the invalid or unenforceable provision will be deemed superseded by a valid and enforceable provision that most closely matches the intent of the original provision and the remainder of the agreement shall remain in full force and effect.

Contact Us

Thank you for choosing our products! If you have any questions or comments,
contact us and we'll address your issues ASAP!

wahsing1984@gmail.com

