


ASSEMBLY INSTRUCTIONS

B0501a




①



B×1
C×4
D×4
G×1

②



A×1
E×4
F×4
G×1

A 1x	B 1x	C 4x	D M8x30mm 4x	E M6x16mm 4x	F 6x18mm 4x	G 1x
--------------------	--------------------	--------------------	--------------------------------	--------------------------------	-------------------------------	--------------------