


Display cabinet

Assembly Instructions - Please keep for future reference



Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightened properly

WARNING In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-









Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type


Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A x76 	B x76 	C x1 	D x2 
E x1 	F x1  M4x18	G x2 	H x4  M6x40
I x4  M4x30	J x18  M3x12	K x4 	L x1  M4
M x4  M3x14	N x1 	O x2 	P x8 
Q x4 			

Ruler - Use this ruler to help correctly identify the screws




Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.




You should feel a click when the camlock is locked in place.

The joint is now secure.

4





Tools required

















Screwdrivers can be converted to Phillips and Slotted.

















Assembly Instructions



Assembly Instructions


①  1	②  2
③  1	④  1
⑤  1	⑥  1
⑦  1	⑧  2
⑨  1	⑩  1
⑪  1	⑫  1
⑬  1	⑭  1

Assembly Instructions



15  1	16  1
17  1	18  1
19  1	20  1
21  1	22  1
23  1	24  1
25  1	26  1
27  1	28  1
29  2	30  1

Assembly Instructions

Step 1





Step 2



Assembly Instructions


Step 3



B x5




Step 4



Assembly Instructions



Step 5



(K) x4

(B) x3



Step 6



(B) x9

Assembly Instructions



Step 7



(B) x2



Step 8




(B) x4



Assembly Instructions


Step 9



(A) x1



Step 10




(A) x37



Assembly Instructions


Step 11



(B) x6






Step 12



Assembly Instructions




Step 13



(B) x6



Step 14



(B) x5





(Q) x4



Assembly Instructions



Step 15



(B) x6



Step 16





(B) x4



Assembly Instructions



Step 17



(B) x10



Step 18




(B) x3




Assembly Instructions

Step 19





Step 20



D x2 	E x1 	J x6  M3x12	F x1  M4x18	C x1 
--	--	---	---	--


Assembly Instructions

Step 21





(H) x4
M6x40

(L) x1
M4




Step 22



(B) x1

Assembly Instructions


Step 23




(A) x4



Step 24




(B) x4




Assembly Instructions

Step 25



Step 26




I x4



M4x30


Assembly Instructions

Step 27



J x4
M3x12

Step 28




M x2
M3x14


N x1

Assembly Instructions

Step 29






Step 30



Assembly Instructions

Step 31



Step 32

