
















ASSEMBLY INSTRUCTIONS MF227-00-GLS-CL



<p>A</p>  <p>1</p>	<p>B</p>  <p>2</p>	<p>C</p>  <p>1</p>	<p>D</p>  <p>1</p>
<p>E</p>  <p>6</p>	<p>F</p>  <p>6</p>	<p>G</p>  <p>4</p>	<p>H</p>  <p>4</p>
<p>I</p>  <p>1</p>	<p>J</p>  <p>4</p>	<p>K</p>  <p>8</p>	<p>L</p>  <p>6</p>
<p>M</p>  <p>1</p>			