



INSTRUCTION MANUAL

Outdoor Patio Rocking Chair

Item NO.: OPRC-M04-BEIGE+C+OPRC-M04-RED
IF YOU PURCHASED THE CHAIR ONLINE AND HAVE ANY
QUESTIONS OR CONCERNS

PLEASE CONTACT US WITH EMAIL OR WHATSAPP

Email: service@joysidefurniture.com

QR code:+86 188 0100 6086



WhatsApp QR Code

WARNING:

Proper use of the sets.

The chair is not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only. Chair tested for use at weight of 300lb (136.4kg). Improper use of this product or failure to use as directed may result in injury. Not intended for commercial use.

IMPORTANT:

Please read all the instructions and warnings before assembling. In order to make the whole product adjust to the best, please install all the screws on the product before fully tighten, and note to put the washer to the screw before putting the screw into the screw hole.

SAFETY INFORMATION:














- Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the product construction.
- Keep assembly area at least 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line or electrical wires.
- Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- Check all bolts for tightness before use. **IMPORTANT** - check and tighten bolts often to keep them secure!
- The chair is not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only.
- The chair use at weight of 300lb (136.4kg). Improper use of this product or failure to use as directed may result in injury. Not intended for commercial use.


CARE & MAINTENANCE :

- **STAIN RESISTANT CUSHIONS CARE :** KEEP THE CUSHIONS IN STORAGE IN RAINING DAY.
- **SPIILLS:** Immediately wipe up the spill using a white damp cloth. Repeat process if necessary until stain is gone. Allow cushion to air dry.
- **FABRIC CARE:** Hand wash cold, non-chlorine bleach when needed, lay flat to dry. Cool iron if necessary. Do not dry clean.
- **RESIN WICKER PRODUCT CARE:** Before using, clean the product completely with a soft dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water, rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. Over time nuts and bolts can loosen. Occasionally, check nuts and bolts on all chairs and tables, re-tighten if necessary.


Rocking Chair

Parts List:


No.	Part	Qty	Image	No.	Part	Qty	Image
A1	Left Arm	1		A2	Right Arm	1	
B	Chair Back	1		C	Seat Panel	1	
D	Big Washer	10		E	Screw(φ6x15mm)	8	
F	Screw(φ6x35mm)	2		G	Allen Wrench	1	
H	Runner	2		I	Tapping Screw	4	
J	Small Washer	4					
							
Step 1: Do not fully tighten now.				Step 2: Do not fully tighten now.			




Step 3: Do not fully tighten now.



Step 4: Do not fully tighten now.



Step 5: Attach runners (H) to assembled rocker and secure by using Tapping screws (I) and small washer (J). Please make sure the direction of runner is



Step 6: Verify the alignment and adjust, fully tighten all the screws now. Put cushions on the rocker. The rocker is assembled.



IF YOU PURCHASED THE CHAIR ONLINE AND HAVE ANY QUESTIONS OR CONCERNS PLEASE CONTACT US WITH EMAIL OR WHATSAPP
 Email: service@joysidefurniture.com
 QR code: +86 188 0100 6086



WhatsApp QR Code

THIS ROCKER IS NOT A TOY. DON'T OVER-ROCK THE CHAIR. IT MAY MAKE THE ROCKER TIP OVER AND RESULT IN INJURY.