

Assembly Instructions

Caution: You must read this before you proceed.

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Crane




Parts List

Label	Picture	Description	QTY
A		Crane	1

Hardware


Label	Picture	Description	QTY
①		Stake	2
②		Hammer (not provided)	1

Step 1



Unpack and place all parts on a clean soft surface.

Step 2



Affix the Crane(A) to the ground by inserting the Stake(①) through the mounting position with Hammer(②).

Step 3



Your crane is ready for use.