




Adapt[®] Premium Adjustable Wreath Hanger Instructions



Locate button
on back



Press button
firmly



While pressing button,
pull on lower assembly

For questions or concerns please contact us directly at customerservice@haute-decor.com