



Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required.

CODE	QTY	HARDWARE
1	4	1/4" x 18mm Allen Bolts 
2	4	Φ 6.5 Spring Washers 
3	4	Φ 6.5 δ1.5 x φ19 Flat Washers 
4	1	Allen Wrench 

CODE	QTY	COMPONENTS	CODE	QTY	COMPONENTS
A	1	Top 	B	2	Base 



STEP 1

Attach Top (A) to Base (B) using 4 Allen Bolts (1), 4 Spring Washers (2), and 4 Flat Washers (3). Tighten all bolts using Allen Wrench (4) provided. The assembly is now complete.

⚠ WARNING

- Do not let any sharp objects touch or rub the surface of the product.
- When assembling, do not let children play around the working area.
- Please confirm all parts are correct before starting the assembly process.
- Do not tighten all bolts and screws completely until the entire unit has been assembled and set up.
- Be careful if using power tools as they can over tighten screws and strip threads.