


FREESTANDING BATHTUB

INSTALLATION & CARE GUIDE

Freestanding Acrylic Bathtub

Please read this guide before installation and keep it for future reference.



IMPORTANT

Before You Begin

Thank you for choosing Easyroom. This guide provides general installation, care, and warranty information for a freestanding acrylic bathtub. Keep all packaging until the product has been fully inspected and installed.

1 Read all instructions first

Review the complete guide before beginning installation.

2 Professional installation recommended

Because plumbing connections and leveling require care, installation by a qualified plumber is recommended.

3 Inspect before installation

Do not install a bathtub that appears damaged. Inspect the finish, drain, overflow, and included components before proceeding.

4 Protect the surface

Use a soft cloth or blanket whenever the bathtub is placed on its side or upside down. Never lift or carry the bathtub by a decorative panel or edge.

Note: Verify that the installation area, floor structure, plumbing connections, and access route are suitable before installation.

Table of Contents


01	Pre-Installation Checklist	4-6
02	Tools Required	7
03	Installation Instructions	8-14
04	Care & Maintenance	15-16
05	Limited Warranty	17-18

PRE-INSTALLATION CHECKLIST

Inspect the Bathtub

Carefully remove the bathtub from the carton or crate. Two people should lift the unit. Place it on a soft blanket over clean cardboard to protect the finish.

us, the contact information is listed on the bottom of each page.




- Inspect the bathtub for visible shipping damage, cracks, chips, scratches, or deformation.
- Confirm that the drain and overflow components are present and undamaged.
- Do not continue with installation if damage is found. Keep the packaging until inspection is complete.

PRE-INSTALLATION CHECKLIST

Leak Test, Fit & Floor Support

ix the leakage.



Leak test

Measurement and fit Measure the final installation space and confirm the bathtub dimensions fit. Place a tray beneath the drain area, add water, and inspect the drain connection and piping for leaks.

- Place a tray beneath the drain area, add water, and inspect the drain connection and piping for leaks.
- Measure the final installation space and confirm the bathtub dimensions fit.
- If a leak is detected, disassemble and reseal the affected connection before installation.
- Check doorways, hallways, turns, and other access points before moving the bathtub into the room.
- Confirm the floor can support the bathtub, water, and occupant load; reinforce the floor if required.

PRE-INSTALLATION CHECKLIST

Site & Plumbing Checks

1 Plumbing connections

Confirm the existing drain and overflow arrangement is compatible with the bathtub.

2 Accessibility

Leave enough room for installation, drain connection, inspection, and future service.

3 Leveling

Verify the floor is level so the bathtub will not rock, shift, or carry load on the side walls.

4 Drainage

Make sure the drain line is clear and functioning before the bathtub is connected.

5 Utilities

Confirm required water and drain lines are accessible. If the product includes powered features, verify electrical requirements separately.

6 Installation materials

Gather all tools, sealants, shims, and connection parts before beginning.

INSTALLATION PREPARATION

Tools & Materials

Have the following items available before installation. Exact plumbing fittings may vary by local installation conditions.

1

Level

2

Soft cloth / blanket

3

Tape measure

4

Pencil

5

Construction adhesive

6

Hammer

7

Silicone caulk

8

Shims / lumber

9

Utility knife

10

Plumber's putty

11

Adjustable wrench

12


Furring strips

INSTALLATION STEPS


Prepare & Position

STEP 1

Prepare the installation area. Ensure the floor is level and structurally suitable. Measure the space and confirm the bathtub fits before connecting plumbing.

**STEP 2**

Position the bathtub. Carefully place the bathtub in the intended location. Use a level to confirm it sits evenly. Add shims if needed to stabilize the unit.




INSTALLATION STEP 3

Mark the Final Location

STEP 3

Use a pencil to mark the exact outline of the bathtub and the drain opening on the floor. Then move the bathtub away so the drain and waste connection can be prepared.



Tip: Keep the marks visible until all plumbing measurements and connections have been confirmed.


INSTALLATION STEP 4

Adjust the Leveling Feet


STEP 4

Turn the bathtub upside down on a soft blanket. Adjust the feet so the tub will be stable and the load will be supported by the leveling feet rather than the bathtub walls.

set it on
scratch-



1. Then raise the leveler an additional 1/8" or 3/16" so that the weight, and user are fully supported by the feet adjuster and not the tub w

**! Leveling reference**

The source guide recommends raising the leveler approximately 1/8 in. to 3/16 in. after initial contact, so the weight of the tub, water, and user is fully supported by the feet.
Customer Support: SZshilei@outlook.com



INSTALLATION STEP 5

Measure & Cut the Tailpiece

STEP 5

Measure and cut the drain tailpiece to the length required to reach the trap adapter. Insert the tailpiece with the 1-1/2 in. slip-joint connection and rubber washer, then tighten the connection securely.

then properly



Important: Dry-fit the parts before final tightening. Confirm the drain path is aligned and free from excessive stress.


INSTALLATION STEP 6

Connect the Drain

STEP 6

Flip the bathtub upright and carefully set it into position. Connect the tailpiece assembly to the waste line and drain. Ensure all fittings are tight, properly aligned, and supported.

ight and secure. Use a P-trap and tailing elbow to connect the drain to the existing plumbing.



Use the supplied drain components together with an appropriate P-trap and connection fittings for the existing plumbing system.

INSTALLATION STEPS 7-8


Secure & Seal

STEP 7

Secure the bathtub. If the bathtub uses floor anchors, brackets, or other stabilizing hardware, secure them as required. Confirm the tub does not rock or shift.

STEP 8

Caulk the seams. Apply silicone caulk around the base where the bathtub meets the finished floor. Allow the sealant to cure before use.



24 Cure time

The source guide indicates a 24-hour cure period before use. Follow the cure time printed on the sealant you use.
Customer Support: SZshilei@outlook.com

INSTALLATION STEPS 9-10


Test & Finish

STEP 9

Test the bathtub. Fill the bathtub with water and inspect all drain connections for leaks. Confirm the drain operates correctly and the bathtub remains stable.

STEP 10

Finish and clean up. Trim excess cured sealant if needed, remove installation debris, and wipe the bathtub using a soft cloth and mild cleaner.



If any part of the installation is uncertain, stop and consult a qualified plumbing professional before using the bathtub.

ACRYLIC BATHTUB

Routine Care

After each use

Rinse with warm water to remove soap residue and loose debris. Wipe the surface dry with a soft cloth or sponge.

Weekly

Use a non-abrasive cleaner suitable for acrylic. Clean gently with a soft sponge or soft-bristle brush, paying attention to the drain and surrounding areas.

Monthly

Inspect caulk and seals for cracks or gaps. Clean the drain and remove hair or debris as needed.

Seasonally

Perform a deeper clean using an acrylic-safe cleaner. Avoid strong solvents, abrasive pads, and harsh chemicals.

ADDITIONAL CARE

Protect the Acrylic Surface

- Avoid abrasive cleaners, scouring pads, stiff brushes, and harsh chemicals that may scratch or dull the finish.
- Do not place sharp or heavy objects directly on the bathtub surface.
- Wipe up soap, shampoo, bath oils, and other products rather than allowing residue to remain for long periods.
- Avoid drastic temperature changes. Do not pour boiling water directly into a cold acrylic bathtub.
- For cleaning, the source guide advises keeping water below 120 F (49 C).
- Inspect the bathtub periodically for cracks, leaks, chips, or other damage and address issues promptly.
- Keep the bathroom ventilated and wipe excess moisture from the tub surface after use.

Cleaning products

Use only cleaners labeled safe for acrylic. Test any unfamiliar cleaner on a small inconspicuous area first.

Proper care and regular inspection help preserve the appearance and function of the bathtub over time.

WARRANTY COVERAGE

1-Year Limited Warranty

Easyroom products are intended to provide reliable service under normal residential use. For defects in materials or workmanship identified within one year from delivery, Easyroom may, at its option, provide replacement parts, replace the affected product or component, or otherwise resolve the claim in accordance with the terms below.

1 Eligibility

This limited warranty applies to the original purchaser. Proof of purchase is required for a warranty claim.

2 Installation

Professional installation by a qualified plumber is recommended. Damage caused by improper installation, misuse, abuse, or failure to follow installation and care instructions is not covered.

3 Costs outside the product

The warranty does not cover removal, reinstallation, labor, or other incidental costs unless required by applicable law.

Warranty decisions are made after review of the claim information and the condition of the product.

LIMITED WARRANTY

Limitations, Claims & Service

Limitations and exclusions. Coverage does not apply to damage caused by negligence, misuse, abuse, improper installation, accidents, hard-water or mineral deposits, corrosive materials, improper maintenance, unauthorized alteration, or failure to follow the care and installation instructions.

Inspection responsibility. The installer or building contractor should inspect the unit before installation. A bathtub with visible defects or shipping damage should not be installed until the issue is resolved.

Transit damage. Shipping damage should be documented promptly and reported through the seller or applicable carrier process.

When requesting warranty service

Please have the following information available:

- Copy of the original invoice or proof of purchase
- Installation date
- Description and clear photos of the issue
- Model number or product description

Customer Support

SZshilei@outlook.com

Include your order information and clear photos when contacting support.