TOOLS REQUIRED




Phillips Screwdriver

(Not Included)



Hammer (Not Included)





Recommended

ASSEMBLY RATING



EASY → DIFFICULI

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



	Are you missing anything? Double-check all parts, hardware and		Check out our Quick Tips!
	accessories listed on Page 6 are accounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
	Should we send any replacements?		Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!		Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


Note:

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.












Screw the cam bolt into panel.



Insert the cam bolt into the bolt hole of joint panel.



Align the cam lock with its side opening (or arrow) pointing to cam bolt.



Turn the cam lock clockwise gently until it will not turn any more.

COFFEE TABLE




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


5 20PCS 6 2SETS 7 4PCS

9 4PCS 10 2PCS 11 2PCS

1.97"

0.67"





A6 1PC

(8) 2PCS

12 8PCS


S


0.39"


GET READY

Please group boards as below.

A 2PCS	B 2PCS	■ 2PCS	€ 2PCS
	o o		0 0
② 2PCS			
D 2PCS	1 1PC	① 2PCS	
		نىن	
● 2PCS		№ 2PCS	N 2PCS
			•
© 2PCS	1 2PCS	2PCS	
			Body
1 2PCS	1 PC		
			Doors /Glass








4


Part B x2PCS


Part **(E)** x2PCS Part **(F)** x2PCS


Hardware ② x8PCS





Please refer to page 5 for detailed instructions on how to fasten cam locks (#2) to cam bolts (#1).













Part 1 x2PCS



13



14

ASSEMBLY COMPLETED



Please ensure the furniture rests on an ever and flat surface. If the produst wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

√ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

