HG-HS411-893 打印机置物架带轮子(三层带抽46cm长)安装说明书 英

Installation Instructions


I. List of Accessories.




① 2 Supports



② 3 Laminates



③ 1 Drawer Laminate



④ 1 Drawer Panel



⑤ 1 Drawer Backpanel



⑥ 1 Drawer Side Panel



⑦ 2 Drawer Bars



⑧ 1 Drawer Handle
A Long Socket Head Cap Screw
D Cross Screw





⑨ 2 Band Brake Wheels
B Short Socket Head Cap Screw
E Pan Head Screw





⑩ 2 Wheels without Brake
C Pointed Socket Head Cap Screw
F Nut

Ⅱ. Installation Diagram.












Note: The distance from the hole on this side to the edge is small, and it must be installed facing the front.



5





The installation is completed.


III. List of Accessories




① 2 Supports



② 3 Laminates



③ 1 Drawer Laminate



④ 1 Drawer Panel



⑤ 1 Drawer Backpanel



⑥ 1 Drawer Side Panel



⑦ 2 Drawer Bars



⑧ 1 Drawer Handle
A Long Socket Head Cap Screw
D Cross Screw





⑨ 2 Band Brake Wheels
B Short Socket Head Cap Screw
E Pan Head Screw




⑩ 2 Wheels without Brake
C Pointed Socket Head Cap Screw
F Nut


Ⅳ. Installation Diagram








Note: The distance from the hole on this side to the edge is small, and it must be installed facing the front.


B
B
7
This way is the front.


4
A
A
A
A
A
A
A
A
A
2
2

5



The installation is completed.