


To assemble chairs

Push with force to ensure the legs and caps are fixed properly. The leg collar should sit firmly against the joint.




Please note the following information:

- A. During assembly children should be kept away from the product due to possible risk of injury.
- B. Do not use this item if any components are missing or damaged.
- C. No tools are required to assemble this product.
- D. **CARE INSTRUCTION:** Wash or clean with soap and warm water after.
- E. Suitable for both indoor and outdoor use.
- F. **IMPORTANT:** Retain these instructions for future reference.

To assemble table

Push with force to ensure the legs and caps are fixed properly.



Top fits snugly on to table base (complete with plug).

Plug for use with sand and water play.

Remove the plug to release the sand or water after use.

