

USER MANUAL



Scan installation

RGB FLOOD LIGHT

Search for "HappyLighting" download



Instruction manual

- The lamp cannot be connected to the dimmer. If the lamp is connected to the dimmer, it will be abnormal, flashing, or unable to connect, etc.
- It is not allowed to use the lamp in the sealing fixture under any conditions, which will seriously shorten the life of the lamp and the connection is abnormal.
- The metal will shield the Bluetooth signal of the lamp and can only be used for glass, plastic, cloth, paper, etc. The wall will weaken the Bluetooth signal.
- Apple IOS can control and connect 6-8 lights at the same time, and Android can control and connect 3-4 lights at the same time.
- The lamp can only be controlled and connected by one device. It is not possible to control and connect one lamp at the same time with multiple devices. If you need to replace the device control the lamp, disconnect the previous device from the lamp or turn off the APP on the previous device.
- Please match within 15 feet. The optimal control distance between the phone and the lamp is within 30 feet. Some lamps are disconnected when they are over 50 feet, and most lamps are disconnected when they are more than 65 feet. The more lamps are controlled and connected by the device, the shorter the control distance.
- The device will be disconnected when the lamp is between 50 feet and 65 feet away from the device. The device will automatically reconnect within 30 feet of the lamp. If it does not automatically connect the lamp, connect it manually.

Product supported device systems:
Android 4.3 or higher, IOS 8.0 or higher

2

Clickable

Store Key

Store the color of the color wheel in the button. Next time you need it, one button will start.

Not DIY

Red, green, blue, mixed color

Shake phone

Randomly change Colors or Style or Songs, only valid in Adjust, Style and Music.

3

Group Manage

Click to group or change the name

Click to select or cancel (All group)

Device List

Click to select or cancel (Single lamp)

Connection Status

Can be connected or disconnected manually

Click to turn the lamp on or off

Increase grouping

Hold on to Drag device

Delete device

(Press and hold the device to the right)

4

Click to start Tape


Single cycle

Random song

Loop song

Note: Please turn off the auto lock screen and the power saving mode when the device is in the tape mode. Otherwise, the App's tape mode will be forcibly closed within a few minutes after the device auto lock screen.

5




Swipe up to display the connected lamp

Click to set the timer
Display the status of the "operat"

Turn timer on or off

6



Choose the command you want to execute (ON/OFF)

Must be open

Tip: If the device requires the lamps to turn on regularly, the lamps turn on the last used setting, not the setting when the lamps is timed.

7

1. Why can't the app connect to the device or operate?
answer:
(1) Please confirm the device Bluetooth is turned on.
(2) Please confirm that the wall switch connected to the lamp is turned on.
(3) Please confirm that the lamp is not connected to other devices.
(4) If the lamp cannot be connected for a long time. Please turn off the wall switch connected to the lamp, then turn it on, and restart the device Bluetooth and app, then clear the device cache.
2. Why does it show that my device connected to the lamp, but can't control it?
answer:
(1) Please confirm that the selected lamp group on the device is the one you want to control.
(2) Please confirm that the lamp on the APP is turned on.
3. Why is the wall switch of the lamp turned on, sometimes I can't find my lamp on the APP?
answer:
(1) Since the device and the lamp take a while to run and connect, it usually appears in the APP after a few seconds. If it does not appear, close the APP and restart.
(2) Please confirm that the lamp is not connected to other devices.

If you have any question or get defective lights, please contact us customer service center (the seller), we will give the solution within 24 hours.

8

Remote control function

Brightness Adjustment

Turn off


Turn on

16 Fixed Colors

4 Modes

9

Product details



Rotation Fixed

10