

# Assembly & Installation Instructions

**\*IMPORTANT: "The Adjustable Nut" Needs to be untightened to extend Arch Pole Fully**


(Adjustable Nut is already attached on the pole. Please find part and untighten to extend arch pole.)

## CAUTION:

Read instructions carefully and ensure a dry and lighted assembly area.

## WARNING

Wires and cables are all attached "further wiring is not needed from consumer". When unpacking product, be careful to not pull wires as it may result as a bad connection. Do not plug into electrical outlet until lamp is fully assembled.



Enclosed:  
All parts are already  
attached in place.

## Assembly Instructions:

\*Unpack and place all parts on surface or floor

1. Insert the threaded side of "Pole A" into the "Base".  
**\*NOTE:** The threaded bottom portion of "Pole A" can be extended by unscrewing. Adjust accordingly to ensure that "Pole A" and the "Base" are securely fastened.
2. Tighten the pole from the bottom of the "Base" with the nut and washer.
3. Use screwdriver to unscrew the "Screw" located on "Arch Body".
4. **Attach the "Arch Body" to "Pole A" then use the screwdriver to reattach the screw back onto the "Arch body".**
5. Place the "Lamp Shade" onto the "Socket" then tighten it up with the plastic "Ring".

**LAMP IS TO BE USED IN A CORNER WALL  
SURFACE ONLY**

## Additional Notes:

1. To extend the "Arch Body" loosen the "Adjusting Nut" completely. With a firm grip, pull or push the end of the "Arch body" to adjust the length of the lamp. If body becomes too stiff to adjust, lightly tug or push the wire at the "Wire-Opening" (repeat as necessary, till desired length).
2. Turn the power off (unplug from the wall outlet) before replacing the bulb. Make sure the bulb has sufficient time to cool down.

## Cleaning:

Use only soft cloth to dust and clean fixture. Never use chemicals or abrasive cleaners as it may damage finish.