



## End Table Assembly Instructions

### Step one: Attach legs

Flip the end table over on its top. Align the leg up with the pre-drilled holes. With the screw provided, screw the leg into the apron. Repeat this step on each remaining leg.

### Step two: Attach shelves

Insert screw into the pre-drilled hole on the bottom of each corner of the shelf (shown in photo). Screw the shelf into each leg. Lining the shelf up with the pre-drilled holes will ensure each shelf is level. Repeat this step for each corner of the shelf and then for the second shelf. \*Be careful not to over tighten, as this may lead to cracking.



### Step three: Adjustable feet

Each foot of the table has an adjustable felt foot to help keep the table level on uneven surfaces. Twist the foot to the left to increase height, or to the right to decrease height. If using a drill, set it somewhere in the middle to ensure you do not over tighten a screw. Over tightening may lead to cracking. Extra screws may be included.



Note: Real wood expands and contracts, so the legs have adjustable felt feet. You may need to adjust the feet seasonally so the table sits flat.