

Brightech® Lucas Assembly & Free Extended Warranty Instructions

1. Screw pole 1 clockwise into the base until tight. Ensure the wire isn't caught in the threading.
2. Screw pole 2 clockwise into pole 1 until tight. Ensure the wire isn't caught in the threading.
3. Screw pole 3 clockwise into pole 2 until tight. Ensure the wire isn't caught in the threading.
4. Screw pole 4 clockwise into pole 3 until tight. Ensure the wire isn't caught in the threading.
5. Insert the harp into the yoke.
6. Unscrew the finial from the harp, place the shade over the harp's threaded nipple and screw the finial over the shade to secure it to the harp.

Extend Your Warranty From 3 Years To 5 Years

To extend your warranty by 2 extra years for a total of 5 years' warranty, register your purchase by filling in the brief form at brightechshop.com/pages/extended-warranty/.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug one blade is wider than the other as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER THE PLUG.**

Max Wattage: 150 watt incandescent or 42 watt CFL equivalent.

A 9.5 watt LED bulb is included. (Incandescent/CFL not included)

Customer Service

Thank you for your purchase of your Brightech lamp. Please contact us via our website or email if you have any issues or concerns.

www.brightechshop.com

wecare@brightechshop.com

