

3 PC LAMP SET

ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:






1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to the start of assembly.
3. Please follow attached instructions in the sequence indicated to assure fast and easy assembly.









Warning!

Do not attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION

TABLE LAMP		
DESCRIPTION	FIGURE	Q'TY
E. Finial		2 pcs
D. Shade		2 pcs
C. Harp		2 pcs
B. Socket Section		2 pcs
A. Lamp Body		2 pcs

FLOOR LAMP		
DESCRIPTION	FIGURE	Q'TY
H. Finial		1 pc
G. Shade		1 pc
F. Harp		1 pc
E. Decoration Section		1 pc
D. C. B. Center Pipe		3 pcs
A. Base		1 pc

NOTE: QUANTITIES SHOWN ARE FOR THREE LAMPS

Assembly time 40 minutes. 1 person needed.

TABLE LAMP


Assembly Instruction

1. Carefully unpack and lay out all parts on smooth surface.
2. Screw Socket Section(B) into Lamp Body(A), pull the cord through the base.
3. Insert Harp(C) into the saddle of Socket Section(B).
4. Place Shade(D) onto Harp(C), tighten by Finial(E) and make the shade keep horizontal.

Use 3-Way 100W (Maximum)
Type A Bulb(Bulb not included)

CAUTION IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.



FLOOR LAMP

Assembly Instruction

1. Carefully unpack and lay out all parts on smooth surface.
2. Screw Center Pipe(B) into the Base(A), then screw Center Pipe(C), Center Pipe(D), Decoration Section(E) to each other one by one, pull the cord through the base.
3. Insert Harp(F) into the saddle of Decoration Section(E).
4. Place Shade(G) onto Harp(F), tighten by Finial(H) and make the shade keep horizontal.

Use 3-Way 100W (Maximum)
Type A Bulb(Bulb not included)

CAUTION IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

