





Instruction Manual

Please save this manual for future reference.

Product Name:	Wood and Metal Farmhouse Distressed Console Table
----------------------	---


PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.

ID	Description	Qty	ID	Description	Qty
A	Table top 	1	B	Table Leg1 	4
C	Shelf 	1	D	Table Leg2 	4

Tools required for assembly: No tools required for assembly.

STEP1



Instruction Manual

Please save this manual for future reference.


Product Name:	Wood and Metal Farmhouse Distressed Console Table
----------------------	---

Assembly Instructions:

Place table top upside down on a soft surface to avoid scratching the table top. Attach (B) legs to the bottom of the table top as shown in the image above. Then insert the shelf into the bottom of the (B) legs, and screw on the (D) legs to firmly attach the shelf to the table legs. Be care not to overtighten to avoid stripping of the screws.

Gently turn table upright. Give it a gentle shake to ensure that it is stable. Tighten legs as needed.

Enjoy your new console table!



WARNING: FOR YOUR SAFETY! To avoid injury and/or damage, please do not sit or stand on the table as this may cause serious bodily injuries and/or product damage.