



ATTENTION


If there is any missing, please kindly send us messages to let us know the part number of missing part regarding to the first page of instructions.

Please also provide your full address, recipient name and contact phone number so that we can send replacement to you as soon as possible.

Children have died from furniture tipover. To reduce the risk of furniture tipover. ALWAYS install tipover restraint provided.


PART LIST





∅6x35MM
Ax25+2


∅15x10MM
Bx25+2



∅6x30MM
Cx28+2


M4x40mm M4x12mm
Dx2


M3x14mm
Ex3



M4x35mm
Fx4



M4x22mm
Gx2



M3x16mm
Ix4



M4x12mm
Jx18+1


M34x12x1mm
Kx1



96mm
Lx1


M90x90x22mm
Mx2
















M46x17x13mm
Nx1


M133x25x5mm
Ox2



M17x14x12mm
Px4


∅21x100MM
x1


PART LIST

1 x1 	2 x1 	3 x1 
4 x1 	5 x1 	6 x1 
7 x1 	8 x1 	9 x1 
10 x1 	11 x1 	12 x1 
13 x1 	14 x1 	

D =




1



2





3



4


STEP1







A		13pcs

STEP2









A		4pcs
B		6pcs
C		4pcs


STEP3







B		4pcs

STEP4




Pay attention to the position of the slot.




C		6pcs
F		4pcs

STEP5




A		4pcs

STEP6




B		2pcs
C		2pcs

STEP7




B		2pcs
C		2pcs

STEP8



B		7pcs
C		8pcs


STEP9




P		4pcs


STEP10

Note: Put the anti-tip deviceD4 on the top, near thebackside, and fix it with a screw D3.




A		4pcs	D		2pcs
E		2pcs	M		2pcs
J		8pcs	N		1pc


STEP11



B		4pcs
C		6pcs




STEP12



E		1pc
G		2pcs
J		6pcs
K		1pc
L		1pc
O		2pcs


STEP13





J		4pcs

STEP14

Be sure to install back plate buckle to prevent the cabinet from shaking.









I		4pcs

STEP15





Drill a hole in the wall, then hammer the D1 into the wall with a hammer.

Note: Follow step
link D4 and D1 with a D2 using a screwdriver,and assembly it tightly.

Note: When moving the cabinet, please lift it vertically off the ground. Dragging may cause loose connectors, affecting stability and service life.

D		2pcs