

ARCHITECT FLOOR LAMP

PACKAGE CONTENTS

A	Base
B	Pole
C	Pole
D	Pole
E	Small screw
F	Arm
G	Large screw
H	Nut
I	Springs x 4
J	Screwdriver



WARNINGS AND CAUTIONS

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock and fire, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this plug.

PREPARATION

Before beginning assembly and installation of product, make sure all parts are present. Compare parts with package contents list and diagram above. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

ASSEMBLY AND INSTALLATION INSTRUCTIONS

Layout all lamp parts from the box and put them on a flat surface.

1. Screw pole (B) onto lamp base (A) clockwise to tighten
2. Screw pole (C) into the pole (B) clockwise to tighten.
3. Attach pole (D) onto the pole (C) by screwing small screw (E) using the screwdriver (J).
4. Attach large screw (G) to orifice on top of the arm (F) near the shade using the screwdriver (J) and secure it with the nut (H) FIG 1.
5. Attach the two springs (I) to the lower part of the arm (F).
6. Attach the two springs (I) to the mid part of the arm (F).
7. Install a light bulb. Only use bulbs of the specified type and maximum rated wattage or less.

CARE AND MAINTENANCE

- Clean with soft dry cloth. Do not use abrasives.
- Bulb replacement:
 - Uses 1 x 25 Watt Type A, E26 medium base bulb or LED equivalent (not included)
 - Shut off main power supply before replacing bulbs.

