USER & INSTALLATION GUIDE

Piano-Key Wall-Mounted Coat Rack | Rebrilliant | SKU W116362347

Read this guide before mounting or using the product. Retain for future reference.

1 Product overview

A wall-mounted wooden coat rack with fold-down piano-key-style hooks for coats, hats, scarves and other everyday accessories. The rack arrives assembled; wall mounting is required.

Overall size	**26.77 in W × 4.72 in D × 1.38 in H**
Product weight	3.75 lb
Listed weight capacity	55 lb total (subject to secure installation and wall strength)
Assembly	No product assembly required

2 Before installation

- Unpack and inspect the rack for damage. Do not install a damaged product.
- Check the actual mounting points and hardware supplied with your unit. Hardware quantities and hole spacing are not specified on the product listing.
- Select a sound, level wall location away from electrical cables, water pipes and sources of excessive heat or moisture.
- Use fixings rated for your wall material and expected load. For drywall, fasten into studs where possible; do not rely on drywall alone for heavy loads.
- Tools may include a tape measure, level, pencil, drill and screwdriver. Use suitable protective equipment.

3 Wall mounting

STEP 1 — Position

Hold the rack at the desired height. Use a level to align it horizontally.

STEP 2 — Mark

Identify the actual mounting holes or brackets on the back of the rack and mark their positions on the wall. Do not estimate spacing.

STEP 3 — Prepare

Check for hidden services. Drill pilot holes only where required for the selected anchors or stud fixings, following the hardware manufacturer’s instructions.

STEP 4 — Secure

Install the appropriate wall fixings and attach the rack using its actual mounting arrangement. Tighten securely without overtightening or damaging the wood.

STEP 5 — Test

Confirm the rack is level, flush and firmly secured. Test gently with a light item before normal use.

IMPORTANT: If your unit uses a concealed bracket, keyhole slots or adhesive mounting, follow the hardware supplied with that exact unit. Do not drill through the wood unless expressly designed for that purpose.

4 Using the hooks

- Pull down only the hooks needed, using gentle hand pressure.
- Hang items fully within the hook profile; distribute weight across multiple hooks.
- Remove items before folding hooks back into the rack. Keep fingers clear of moving joints.
- Never climb, pull on or hang from the rack. It is not a grab bar or child-support device.

5 Safety and load limits

The product listing states a 55 lb weight capacity. This is not a guarantee for every wall or anchor configuration. Actual safe capacity is limited by the weakest part of the wall, fasteners, mounting system or rack. Do not exceed the rated capacity. Avoid concentrated loads, sudden pulls and swinging objects. Periodically check for looseness or damage. Keep small installation parts away from children.

6 Cleaning and care

Wipe with a soft, slightly damp cloth and dry promptly. Do not soak, use abrasive cleaners or expose the wood to prolonged humidity or direct heat. Check the wall fixings regularly and retighten if necessary.

7 Troubleshooting

Rack moves or tilts — Stop using it; check the wall material, anchors and fasteners. Reinstall with suitable fixings.

Hook does not move smoothly — Remove the load and inspect for obstruction or damage. Do not force the hook.

Wood finish becomes wet — Dry promptly and improve ventilation.

Product reference

Wayfair SKU W116362347 | Variant ID 768416686. Product dimensions and capacity are based on the linked listing. Mounting hardware configuration must be verified against the actual package before publication.