>>assembly instructions



Congratulations on your latest purchase.

Now what? Don’t start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you’ll be on your way to transforming your room in no time. Good luck --though we’re confident you won’t need it.

before you begin

1. Use the carton as a working surface to prevent product damage during assembly.
2. Gather all tools prior to assembly.

table of contents

introduction	2
hardware	4
parts list	5
assembly	6 - 9

hardware

(A) x 4

5/16" x 60mm
round hex screw



(B) x 4

5/16" x 50mm
round hex screw



(C) x 8

Φ 8mm lock washer



(D) x 8

Φ 22mm flat washer



(E) x 1

5mm Ball end
Hex wrench

ITEM	DESCRIPTION	QUANTITY
1	chair cushion	1
2	front leg	2
3	left back leg	1
4	right back leg	1



step 1.



(A) x 4

5/16" x 60mm
round hex screw



(C) x 4

Φ 8mm lock washer



(D) x 4

Φ 22mm flat washer



(E) x 1

5mm Ball end
Hex wrench

Please do not assemble with power tools.

step 2.



(B) x 4

5/16" x 50mm
round hex screw



(C) x 4

Φ 8mm lock washer



(D) x 4

Φ 22mm flat washer



(E) x 1

5mm Ball end
Hex wrench

Please do not assemble with power tools.

step 3.

1



step 4.

A friendly reminder from us:



Please keep the Allen wrench.

After a period of time, there may be a chance the KD furniture may become loose, please use an Allen wrench to tighten the loose bolts.

Put the chair right and check whether the chair has been well assembled. If it is not assembled, loosen the screw and tighten it on the ground.



Adjustable leveling feet

(This part is already attached on the end cap of 4 legs.)

Level the furniture, use leveling feet if needed.