

Crystal Falls 46" Round Slat Dining Table Item #W22140

Assembly Instructions

****TO AVOID POTENTIAL SCRATCHING TO PARTS BY ROUGH GROUND SURFACE, COVER GROUND WITH SOFT SMOOTH PROTECTIVE MATERIAL ON WHICH TO PLACE PARTS DURING ASSEMBLY. ****

Step 1: Remove protective wrapping and lay all parts on ground. Identify all parts packed in carton against the parts list.

Step 2: Lay Table Top Frame (A) upside down on ground, so bottom is facing up.

Step 3: Then attach each of four Legs (B) to the Top as shown in Diagram 1, using Bolt (D) and Washer(E). Attach Round Stretcher (C) to Legs (B) using Bolt (D) and Washer(E) as shown in Diagram 2. To make sure everything fits properly, do not tighten all bolts until they are all properly in place. Use Hex Wrench(H) to tighten all Bolts.

Step 4: Make sure all bolts are aligned properly and tightened securely. Then place Bolt Covers(F) over bolts. Turn the table to upright position on flat surface as shown in Diagram 3.

NOTE: IT IS USER'S RESPONSIBILITY TO MAKE SURE ALL PARTS ARE ASSEMBLED AND TIGHTENED PROPERLY AND SECURELY.

WARNING!: TABLE IS NOT MEANT FOR SITTING OR STANDING ON. DO NOT SIT/STAND ON OR LEAN FULL BODY AGAINST TABLE. IMPROPER USE MAY LEAD TO PRODUCT DAMAGE AND/OR BODILY INJURY.




Diagram 1




Diagram 2











Diagram 3

PARTS LIST

Ref	Part Name	Part Image	Qty	Ref	Part Name	Part Image	Qty
A	Table Top		1	E	Washer		12
B	Table Legs		4	F	Bolt Cover		12
C	Round Stretcher		1	G	Hex Wrench		1
D	Bolt		12				

WOODARD

Customer Service Hours
 8:00am-5:00pm CST Monday to Friday
 Phone: (800) 877-2290 Fax: (800) 733-4257
 E-mail: retail3@woodard-furniture.com