


ASSEMBLY INSTRUCTION

WF293342/ WF293344


IMPORTANT NOTES:

- 1. PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.**
- 2. BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.**



ASSEMBLY INSTRUCTION

WF293342/ WF293344








ASSEMBLY INSTRUCTION

WF293342/ WF293344

HARDWARE LIST


NO	DESCRIPTION	QTY
A	ALLEN KEY M5 	1 PC
B	JCBC BOLT M8X60MM 	8 PCS
C	FLAT WASHER 5/16 X 1.0 	8 PCS
D	SPRING WASHER WS5/16 	8 PCS
E	SHELF SUPPORT PIN 	4 PCS
F	ALLEN KEY M4 	1 PC
G	JCBC BOLT M6X30MM 	14 PCS
H	SPRING WASHER WS6 	14 PCS
I	CHIPBOARD SCREW SCCB 3.5X16 	4 PCS

PART LIST


1.  TABLE TOP X 1	2.  LEFT TABLE LEG X 1	3.  RIGHT TABLE LEG X 1
4.  NORMAL TABLE LEG X 2	5.  LEFT SHELF SIDE PANEL X 1	6.  RIGHT SHELF SIDE PANEL X 1
7.  SHELF ADJUSTABLE PANEL X 1	8.  SHELF BOTTOM PANEL X 1	9.  SHELF BACK PANEL X 1

ASSEMBLY INSTRUCTION


WF293342/ WF293344

4

Attach the shelf back panel to the Side panel as shown in the picture.

5

Attach the shelf bottom panel to the side panel and back panel as shown in the picture.

6


Insert the shelf adjustable panel to the shelf and secure it as shown in the picture.

ASSEMBLY INSTRUCTION

WF293343 \ WF293345


IMPORTANT NOTES:

- 1. PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.**
- 2. BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.**



ASSEMBLY INSTRUCTION

WF293343 \ WF293345






ASSEMBLY INSTRUCTION

WF293343 \ WF293345


HARDWARE LIST FOR ONE CHAIR		
NO	DESCRIPTION	QTY
A	ALLEN KEY 	1 PC
B	JCBC BOLT M6X80MM 	4 PCS
C	JCBC BOLT M6X60MM 	4 PCS
D	JCBC BOLT M6X30MM 	2 PCS
E	WASHER M6X16 	8 PCS
F	SPRING WASHER WS6 	10 PCS

PART LIST


1  BACKREST X 1	2  SEATER X 1	3  CHAIR LEG X 2
--	--	---

ASSEMBLY INSTRUCTION


WF293343 \ WF293345




Assemble FRONT LEGS L/R to SEAT as illustration shown, screw until tight.



Insert screws and assemble as shown on drawing. Do not tighten screws until fully assembled.



Insert screws and assemble as shown on drawing. Do not tighten screws/bolts until fully assembled.



Tighten all screws & bolts while making sure that the unit remains level.