Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

COUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provider).

| PART LIST |              |     |       | HARDWARE LIST |             |     |
|-----------|--------------|-----|-------|---------------|-------------|-----|
| ITEM      | DESCRIPTION  | BOX | QTY   | ITEM          | DESCRIPTION | QTY |
| Α         | BODY         | 1   | 1 PC  | -             | -           | -   |
| В         | HANDLE       | 1   | 2 PCS |               |             |     |
| С         | HANDLE SCREW | 1   | 4 PCS |               |             |     |
| D         | FLAT WASHER  | 1   | 4 PCS |               |             |     |
| E         | DRAWER       | 1   | 2 PCS |               |             |     |



