


The background of the entire page is a complex, repeating geometric pattern. It consists of numerous thin, light gray lines that intersect to form a series of overlapping triangles and hexagons. The pattern is dense and covers the entire surface, creating a textured, crystalline appearance. The triangles are of various sizes and are arranged in a way that they seem to be layered or stacked, giving a three-dimensional feel to the two-dimensional pattern.


ASSEMBLY MANUAL

BEFORE YOU START




1. TOOLS REQUIRED

Phillips screwdriver, not included.




2. CHECK ALL PARTS

Make sure all panels and hardware are included before assembly.




3. USE A SOFT SURFACE

Assemble on a carpet or protective mat to avoid scratches.



4. DO NOT FULLY TIGHTEN SCREWS FIRST

Tighten screws only after the unit is fully aligned.



5. Recommended: 2 Adults

Larger panels are easier and safer to assemble with two people.



6. KEEP SMALL PARTS AWAY FROM CHILDREN

Small parts may present a choking hazard.

PRODUCT OVERVIEW

Finished Product & Dimensions






Please review the finished product shape and overall dimensions before assembly.

HARDWARE INSTALLATION TIPS


NOTE:

1.






Ensure there is no gap
after tightening




2.



3.




4.




Assembly Time: 30 Minutes

Assembly Difficulty ★★☆☆☆


PARTS




① x1




② x1




③ x1




④ x1




⑤ x1




⑥ x1




⑦ x1




⑧ x1




⑨ x4




⑩ x2




⑪ x2




⑫ x2




⑬ x2




⑭ x2




⑮ x2





M6x35

A x26 +2 spare



M4x35

B x17 +1 spare




M6x30

C x14 +1 spare



M4x18

D x6 +1 spare



M15x10

E x26 +2 spare




M3.5x12

F x18 +2 spare



M4x12


G x20 +2 spare




M6x30

H x4 +1 spare


Scale 1:1




I x4



J x2



K x1



L=250mm
L x4



M x4 +1 spare



M3x14

N x4 +1 spare




P x26 +2 spare

Note: Some screws include extra pieces for your convenience. Please keep them for future use.




A		12
---	---	----

1




F		8
L1		4

2




A		4
---	---	---

3




E		4
---	---	---

4




C		4
E		6

5




C		4
E		6

6




7





B		4
C		4

8





G		20
I		4



9


H		4
---	---	---



10


B		3
C		2

11




F		2
K		1



12



F		8
L2		4




13



x2

B		8
---	---	---


14



x2


B		2
---	---	---

15




A		10
---	---	----

16




E		10
---	---	----


17



D		6
J		2


18





M		4
N		4

20



WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install the provided anti-tip device.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***

SAFETY FIRST, STYLE ALWAYS

Thank you for choosing our product. To ensure safe use and optimal performance, please read and follow the instructions below:

- **Assembly:** Carefully follow all assembly instructions and securely tighten all screws and fasteners.
- **Intended Use:** Use the furniture as intended and do not exceed the stated weight limits.
- **Handling:** Move the furniture carefully and inspect it regularly for loose hardware.
- **Tipping Hazard:** Secure the furniture to the wall using the provided anti-tip device. Failure to do so may result in serious injury.
- **Overloading:** Do not exceed the recommended weight limits, as this may result in damage or injury.
- **Sharp Corners:** Use caution around sharp corners, especially in households with children.

MAINTENANCE & CLEANING TIPS

- **Regular Cleaning:** Use a soft, dry cloth to wipe the surface of the cabinet regularly. Avoid harsh chemical cleaners.
- **Protect from Sunlight:** Keep the cabinet out of direct sunlight to prevent damage to the material and finish.

WE'RE HERE TO HELP.

We don't just sell furniture - we're here for the long haul! If you run into any issues due to manufacturing defects or material problems, we offer a 1-year warranty. That means we'll replace any faulty parts for free - no hassle.