
ASSEMBLY INSTRUCTIONS

- 1. Carefully place all parts on a smooth surface and line them up as per the sketch.
- 2. Remove the ring (B) from the socket, then put the shade (A) onto the socket and turn to tighten with the ring (B).
- 3. Install the bulb, then insert the polarized plug into a wall outlet and enjoy your new lamp. Turn the light on/off using the switch on the cord.
- 4. To clean, use a soft dry cloth only. Never use chemical or abrasive cleaners.

Use a 13W CFL Type bulb or 60W (Maximum) A Type bulb.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

- **** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- **** SAVE THESE INSTRUCTION FOR FUTURE REFERENCES.**

ASSEMBLY INSTRUCTIONS


*** VERY IMPORTANT**

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE YOU SCREWING TO SCREW THEM TOGETHER. TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY!

- 5. Carefully place all parts on a smooth surface and line them up as per the sketch.
- 6. Remove the ring (B) from the socket, then put the shade (A) onto the socket and turn to tighten with the ring (B).
- 7. Use a maximum type A 60 watt bulb.(bulb not included)
- 8. Insert the polarized plug into a wall outlet and enjoy your lamp.

 Turn the light on and off using the on/off switch on the cord.
- 9. To clean, use a soft dry cloth only. Never use chemical or abrasive cleaners.





IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

- **** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- *** SAVE THESE INSTRUCTION FOR FUTURE REFERENCES.**