


ASSEMBLY INSTRUCTIONS.




MISAKI OAK SIDEBORD BLACK



THANK YOU FOR YOUR PURCHASE!

PARTS AND HARDWARE.

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
1.	CABINET		01
2.	LEGS		02
3.	CENTER LEG		01

HARDWARE LIST


No.	DESCRIPTION	IMAGE	QTY
4.	ALLEN BOLT (6x50)		10
5.	ALLEN BOLT (6x35)		02
6.	ALLEN KEY		01
7.	FLAT WASHER		12

NOTES.


Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.

Caution: The item is heavy, assembly should be performed by two people.

STEP 1.



STEP 2.



STEP 3.

