



PR33-Scrolled Arm Oval Cookware Rack

Thank you for choosing Enclume!

Enclume racks are the ultimate quality, design, strength and function.

WARNING: READ ALL OF THE INSTRUCTIONS BEFORE ASSEMBLING AND USING YOUR RACK

If you need help, please call 1-877-ENCLUME

Enclume Design Products

24 Colwell Street, Port Hadlock, WA 98339

Phone 360-385-6100 • Fax 360-385-6156

www.enclume.com



Enclosed you will find everything needed for the assembly and use of your storage rack. Two people make assembly and installation easier. The parts and hardware included are:

Hardware included:

- 6 – 3/8" x 1" Button Head Screws
- 6 – 3/8" Nuts
- 2 – Ceiling Screw Hooks (Large)
- 2 – 5" Extension Hooks
- 1 – 7/32" Allen Wrench
- 12 – Angled Pot Hooks
- 12 – Straight Pot Hooks
- 2 – Grid Brackets
- Toggle Kit


Components included:

- 1 – Oval Base
- 1 – Grid
- 4 – Arms
- 1 – Upper
- 4 – "L" shaped Grid Brackets



See reverse side for ASSEMBLY AND INSTALLATION INSTRUCTIONS

ASSEMBLY AND INSTALLATION INSTRUCTIONS



Rack Assembly

- 1) If your rack is stainless steel it is best to keep the tissue on during installation to avoid fingerprinting.
- 2) Place rack body (also called the oval) on the floor or other "firm" surface.
- 3) Attach the four arms to the OUTSIDE of the oval using the 3/8" x 1" button head screws. From the outside, thread the button head through the arms, the oval and grid bracket (long side down). Secure with 3/8" Hex nut. Make sure the arm orientation is correct. The 90 degree bend is facing towards the center of the rack and is approximately even with the bottom of the rack body. Leave the four button head screws slightly loose.
- 4) Attach the upper bar to the four arms using the two screws and two nuts. Insert the extension hooks into the holes in the upper bar.
- 5) Square up the arms and tighten all the screws with the Allen wrench. The assembly is now complete.
- 6) Carefully place the grid (from one end) between the arms until it fits into the oval and rests on the arm tabs for support. Two people make this step easier.
- 7) We recommend that you anchor your rack into the solid wood of ceiling joists or beams. Carefully measure the area where the rack is to be hung and install the ceiling screw hooks directly into the wood joists. If it is not convenient to hang your rack directly into wood joists you may use the included DRYWALL anchors enclosed with your rack. See Toggler® brand manufacturer recommendations for weight limits included in the instructions in the Toggler kit.
- 8) Hang your heavier items on the straight portion of the rack between the hanging arms or from the upper bar between the extension hooks.



It is important that your rack is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

Limited Warranty: This product is warranted to be free of material defects for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, *postage prepaid* within 20 days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. **THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.**