





Attention: Don't tighten the screw before all screws are in place

UESR'S MANUAL

Hardware List





Panel List






STEP 1

x3





STEP 2


x3





STEP 3





STEP 4





STEP 5




STEP 6




STEP 7



STEP 8




STEP 9



Bx4



STEP 10




Bx5





Cx1



STEP 11



STEP 12



STEP 13



Fx1



STEP 14

