
Electric Height Adjustable Standing Desk

Assembly Instruction




INTRODUCTION


Thank you for purchasing our products. Please read the instructions carefully before installation and keep it in a safe place for future reference. If you need any assistance or support, please feel free to contact our customer support team.

PRECAUTIONS


- 1. There are many components and accessories in the package. Keep them away from children to prevent accidents.
- 2. Please install the product on a clean and soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
- 3. The main components of the product are relatively heavy. Please pay attention to safety during installation.
- 4. The product is not stable during installation. Please do not move it randomly before it is completely installed.
- 5. If you have any questions during installation, please contact the customer service on time.
- * PLEASE BE SURE TO FOLLOW THE INSTALLATION STEPS IN THE MANUAL TO AVOID UNNECESSARY LOSSES CAUSED BY IMPROPER INSTALLATION.
- * IF YOU NEED FURTHER ASSISTANCE, PLEASE CONTACT THE CUSTOMER SERVICE ONLINE.

Parts List




























Please make sure the table legs are vertical to the connecting rod. And then tighten all the screws.






- 1. Please make sure the two boards are aligned and seamless.
- 2. And then tighten the screws.









The table will automatically drop to the lowest point stay for 5 seconds, then rise to the highest point, and finally return to the initial position.

-successful installation



After the table is installed, please press the $\ensuremath{\bigcirc/_{\text{RSFI}}}$ key to start



INSTRUCTION MANUAL

UP AND DOWN BUTTON OPERATION

- * When the "_" button is pressed, the desktop runs up until reaching the highest height.
- * When the "\sqrt{1}" button is pressed, the desktop runs down until it reaches the lowest height.
- * When press the "\[\]" or "\[\]" button, the desktop runs automatically.
- * When press the "___" button 3S, release the button, automatically reach the highest height, press any button can stop halfway.
- * When press the "" button 3S, release the button, automatically reach the highest height, press any button can stop halfway.

LOCATION STORE/MEMORY LOCATION OPERATION

- * Storage of standing position: press and hold "button for 5 seconds, and the standing position is saved.
- * Storage of sitting position: press and hold "up" button for 5 seconds, and the sitting position is saved.
- * Stand memory position operation: press the "b" button, the desktop automatically runs to the height of the memory position, and press any buton can stop halfway.
- * Sitting memory position operation: press the "up" button, the desktop automatically runs to the height of the memory position, and press any button can stop halfway.

RESET OPERATION

* Press and hold" \bigcirc / rest is for 5 seconds, The table will automatically drop to the lowest point, stay for 5 seconds, then rise to the highest point, and finally return to the initial position.

After the assembly of desk, please execute this process first.