


ASSEMBLY INSTRUCTION
L WRITING DESK HUTCH
L WRITING DESK BASE
L WRITING DESK TOP RIGHT RETURN

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

COMPLETED:



PARTS LIST

NO	DRAWING	DESCRIPTION	Q'TY
1		L Writing Desk Hutch	1
2		L Writing Desk and Right Return	1

HARDWARES LIST 1 (422-HO140)

NO	DRAWING	DESCRIPTION	Q'TY
A		Bolt Ø1/4"-20*15(L)	2
B		Flat Washer Ø1/4"*Ø16*2mm	2
C		Spring Washer Ø1/4"*Ø13mm	2
D		Allen key M4	1
E		Tipping Restraint	1

HOW TO REMOVE DRAWER

To remove drawer, simultaneously pull orther and remove drawer. tab up on one side and push down on the

