

ACCESSORIES ITEMS



Coaxial line



Audio signal line



Crystal



Instructions



Infrared Remote Control



Remote control

VANITII

Fireplace

NOTA

- After the first connexion, the two devices matched is connected automatically when this turned on bluetooth function
- If the speaker is connected via bluetooth but does not play sound, please, turn off amboc devices, enciendelos and reconnect
- The SD device can be inserted only in direction, Do not force it because this thing could damage
- The speaker only supports SD devices with system of files AT/FTA 32, max 32GB
- Not all music formats are supported by the speaker, If his music cannot be change to a compatible format play
- Turn off the speaker before removing the SD device
- The USB working mode will not be available if not you have inserted a SD device

vanitii.US

 vanitii

 www.vanitii.com

 sales@vanitii.com

PRODUCT PICTURES




VNT-JAZZ-2202BLK




VNT-JAZZ-1202BLK


BUTTON CONTROLS



1. Power switch on/off
2. 5V output
3. USB / TF card input
4. Aux input
5. Wired microphone input
6. Microphone volume
7. Music volume
8. Light switch on/off
9. ⏮/⏭ Press to skip back or forward to the next track/chapter
10. **REC**: Turn on the microphone, insert a USB drive or TF card, press this button to record, then press again to exit.
11. **▶** Press to start/pause the playback.
12. Audio source input conversion: **Bluetooth/AUX/FM/coaxial**.




13. Press this key to remove the human voice and enable the chorus, then press "Exit" to quit.
14. Light show mode
15. **MENU**:



16. Microphone priority
17. Single song repeat / Random play
18. Music EQ
19. Music Mute

REAR PANEL



20. LED lamp connection

22. AC input(110V)


24. COAXIAL input

21. Speaker connection

23. Heat dissipation holes must not be blocked.

25. Audio input

INFRARED REMOTE CONTROL



26. Press to turn on or activate the "standby" mode when the switch of ignition in the rear panel is in the "on position"

27. Press this button repeatedly to select your desired mode operation between: bluetooth,Fm,USB,SD and online entry

28. Press to select the desired music content by its sequence number in which is stored in the USB dispositive or card SD/MMC to be this playing

29. Press repeatedly to lower/raise the volume

30. Press to mute aduio output,and press again to resume

31. The playback mode has been changed to the stop state.

32. ⏮/⏭ Press to skip back/adelante to following content of music,or station in FM mode

33. ⏩ Press to start playing/pausar,In FM mode ,press to tune with jumps of 0.1 MHz

34. Press to select different mode to play the music repeatedly,"one"to repeat the current track or "all"to repeat all the stored content

Press to start/pause the playback.


35. Press repeatedly to select your desired equalizer mode

ELETRIC FIREPLACE OPERATING INSTRUCTIONS


- For installation of the appliance, care must be taken not to damage concealed cables.
- Please be careful while drilling the holes.

Install crystal

- 1.Disassemble the hardware and glass
- 2.Place the crystal inside the fireplace
- 3.Reassemble the hardware and glass



- After placing the crystals, install the glass and the front frame, and lock the screw.(Fig.2)



Button Controls

Button Controls		Power ON/OFF	Press to turn on/off	
		Flame Color	Short press to change the flamecolor: D1-D13 shown on the screen allows you to switch 13 flame colors. Long press to change the mode of adjusting brightness: L1-L5 shown on the screen allows you to adjust the flame brightness with each press	
		Heating Function	Short press to activate natural wind, shown as "FF" on the screen Press again to switch to heating mode, shown as "H2"	
		Timer Function	Short press to activate the timer function, shown as "0H" on the screen Press again to set time from 1H-9H	

Infrared Remote Control

Infrared Remote Control		Power ON/OFF	Power ON/OFF: Press to turn on/off	
		Dynamic Flame Color Control	Short press to switch 13 flame colors from D1-D13 automatically, shown as "13" on the screen;	
		Single Flame Color Control	Short press to switch 13 flame colors from D1-D13	
		Natural Wind Function	Short press to activate natural wind function, shown as "FF" on the screen Press again to turn it off, shown as "OF"	
		Heating Function	Short press to activate heating function, shown as "H2" on the screen Press again to turn it off, shown as "OF"	
		Timer Function	Short press to activate the timer function, shown as "0H" on the screen Press again to set time from 1H-9H	
		"+" "-" "L" "H"	Short press to adjust the flame brightness	

Technical Specification

Product name: JAZZ fireplace

Supply: 110V AC 50/60Hz (Adapted to American standards)

Flame power: 26 W Heating power: 1500W Sound power: 240W